



How to Change the IP Address of the ProHelp Millennium Host Computer

To change the Internet IP address of a machine, perform the following steps :

- while logged in as user **millen**, from the SCO UnixWare Desktop
- double click on the **Admin_Tools** icon
- double click on the **NetWorking** icon
- double click on the **Internet_Setup** icon
- the screen below will appear



- highlight the Host computer name by clicking on the name (typically the host name has four numbers followed by "mat1", eg. xxxmat1)
- select the **System** menu
- select the **Properties** menu item
- the screen below will appear



- change the **Network Address** to the correct IP address
- **WARNING: DO NOT CHANGE THE SYSTEM NAME**
- click on **Apply** then **OK** to save your changes
- click on the **Actions** menu, then select **Exit**
- click on the **File** menu, then select **Exit** and you are back to the Desktop
- restart the Host computer by clicking on the **Shutdown** icon

NOTE: Modifying the Internet IP address in this way will change the address in several locations, including the **"/etc/hosts"** file. If you need to change the IP address of another monitoring node, you will need to perform these instructions at the node and at the main host. If you have **Exceed** workstations that access the Millennium host, you will need to change the Host IP address at each PC in the Exceed **Xstart** configuration.